

Medical, Dental and Industrial Wireless Keyboard



Hygienic, Washable, Easy to Clean, Antimicrobial, IP68 Dust and Waterproof

Medical grade IP68 waterproof wireless keyboard with Antimicrobial protection

- ✓ 100% Waterproof
- ✓ Dustproof
- ✓ Antimicrobial coating on keyboard and cable preventing microbial infestation

Easy to clean with all common medical cleaning solutions certified for medical usage

Model: SteriClick Pro Wireless Keyboard color: white or black Keyboard Layout: UK

Tel. +44 7780355881

Email: info@stericlick.co.uk

www.stericlick.co.uk



Key Features

Very comfortable and light typing Low profile keys

Turn keyboard ON/OFF

Esc										t Delete	S sec U on/off keyboard	SteriClick® Antimicrobial Protection						
?	0 N	# 3	\$ 4	% 5	^ 6	& 7	*	(9) 0		+=	Ŷ	Back Space	Home	Num	-	* -	
	Q	W	E	R	T	Y			D) { [}			Page Up	7 Home	8	9	
Caps Lock	A	5	D	F	G	H	J	К	L	:	•	Enter 4	£	Page Down		↑ 5	PaUp 	+
ft Shift	Z	X	C	V	В	N	М	< •	> •	? /	ᢔᠴ	hift	Ŷ	End	I 2 3 End ∜ PgDn			
tri 🕬	1	Alt						Alt	WIN	圖	Ctrl	÷	ኁ	⇒	O Ins	000	• Del	Ente

Unique antibacterial coating on keyboard surface

L/W/H: 380mm x 130mm x 14mm IP classification: IP68 water and dust protection Color: white or black Interface: 2.4GHz Mini USB Wireless receiver 'dongle', Plug and play. Easy to install, no drivers needed 2.4GHz digital radio frequency technology with working distance up to 10 meters (30 feet) Automatic synchronization between keyboard and receiver Power: Two alkaline AAA batteries Approvals: CE, FCC, ROHS Warranty: 1 Year limited Warranty Simple steps to set up your wireless keyboard and mouse

- 1. Connect the USB receiver into the USB port on your computer.
- 2. Restart the computer.
- 3. Make sure batteries are installed in both the wireless mouse and in the keyboard.
- 4. Make sure the keyboard is turned on.

Email: info@stericlick.co.uk

www.stericlick.co.uk